



FUSION PLUS™ 6000L FUSION PLUS™ 7000L A3 LAMINATORS

start here

démarrez ici

starten sie hier

iniziare qui

begin hier

empieza aquí

comece aqui

buradan başlayın

ξεκινήστε εδώ

start her

aloita tästä

start her

börja här

rozpocznij tutaj










začňte zde

kezdés itt

начинать здесь

ابدأ هنا







FUSION PLUS™ 6000L **FUSION PLUS™ 7000L** **A3 LAMINATORS**

GB instruction manual	4
F manuel d'utilisation	10
D bedienungsanleitung	16
I manuale d'istruzioni	22
NL gebruiksaanwijzing	28
E manual de instrucciones	34
P manual de instruções	40
TR kullanım kılavuzu	46
GR οδηγίες	52
DK brugsvejledning	58
FI käyttöopas	64
NO bruksanvisning	70
S bruksanvisning	76
PL instrukcja obsługi	82
CZ návod k obsluze	88
H használati útmutató	94
RUS руководство по эксплуатации	100
AR دليل الإرشادات	106



professional finish... automatically!

Welcome to the new GBC Fusion Plus™ 6000L and 7000L laminators which allow lamination to be completed quickly and simply with GBC quality lamination output. Perfect for novice users choosing automatic self setting to expert users with multiple pouch thicknesses and document sizes.

For best lamination results and performance, use only GBC branded pouches.

Please take a little time to study these instructions to ensure you get the best results out of your machine.

safety instructions



Your safety as well as the safety of others is important to ACCO® Brands. In this instruction manual and on the product are important safety messages. Read these messages carefully.



The safety alert symbol precedes each safety message in this instruction manual.

This symbol indicates a potential personal safety hazard that could hurt you or others, as well as cause product damage or property damage.

points to note

- Use this unit only for its intended use of laminating documents
- Only use 75mic, 80mic, 100mic, 125mic, 150mic 175mic or 250mic pouches with this laminator
- Do not laminate an empty pouch
- The unit must be connect to a supply voltage corresponding to the electrical rating shown on the unit
- Ensure the machine is clear of pouches prior to starting the next pouch
- The socket outlet shall be installed near the equipment and shall be easily accessible
- Clean the lamination rollers on a regular basis
- Maximum A3 document pouch 426x303mm
- Active anti jam feature may not detect issue on smaller items
- Failure to comply will result in damage and invalidate guarantee
- Place the unit on a secure, stable work area to prevent the unit from falling and possibly causing personal injury or damage to the unit
- Equipment must be earthed. Only use the power cord supplied with this equipment
- Rating label is on the base of the machine

service

Do not attempt to service or repair the pouch laminator yourself. Unplug the unit and contact an authorised GBC service representative for any required repairs.

technical specifications

Fusion Plus™ 6000L Laminator

Electrical	220-240V / 50/60Hz / 6.5A / 1450W
Machine Dimensions	580x235x120mm (without exit tray) 580x330x120mm (with exit tray)
Machine Weight	7.7kg
Maximum Pouch Width	A3: 303mm

Fusion Plus™ 7000L Laminator

Electrical	220-240V / 50/60Hz / 6.5A / 1450W
Machine Dimensions	580x235x120mm (without exit tray) 580x330x120mm (with exit tray)
Machine Weight	8.1kg
Maximum Pouch Width	A3: 303mm

getting ready to laminate

Easy Set Up

- 1 Remove the plastic exit tray from the box and place into the two holes on the back of the laminator and extend to use. Ensure that there is sufficient space behind the laminator for the item to be removed.
- 2 Take the electrical plug and place in an appropriate power source, which is near the table you intend to use.
- 3 A sequence of lights will cross the control panel.
- 4 To use the laminator gently tap the 'power on' button.

NOTE: Your new laminator may emit a slight odour during the initial operation. Its is normal and will diminish after a few hours of operation.



Manual Select

Fusion Plus™ 7000L only

If you do not wish to use the Auto setting select the pouch thickness using the arrows to scroll until the required pouch thickness setting is shown.



Auto Pouch Setting


Auto Pouch Select (), the laminator automatically measures document and pouch thickness and sets itself accordingly.

NOTE: The machine will not take any pouch during warm up.



loading the pouch

- 1 Take your item to be laminated and place into the laminating pouch. Ensuring it is firmly placed along the sealed edge of the pouch. This is to help ensure that you get optimal quality output.



NOTE: Do not cut pouches prior to lamination.



Before laminating important or unique documents, always run a test pouch through the laminator using a similar type document.

laminating

- 1 On the front of the laminator there are line guides to help you feed your pouch accurately. Always feed your document through the centre of the laminator to ensure accurate thickness measurement.



- 2 Feed the sealed edge of the pouch, into the laminator between the guides. The laminator will grip the pouch and guide it through to the exit tray.



- 3 When you are finished laminating tap the 'power' button and if required remove the tray, unplug and store accordingly.



Upon exiting remove your laminated item immediately and lay on a flat surface to ensure optimal quality.



NOTE: You may notice a change in the engine noise when you feed your pouch and document in. This is due to the laminator changing speed to ensure consistent premium quality lamination.

additional features

Intelligent Pouch Reverse

If pouch misfeed or jam starts to occur a constant beep will be emitted and the laminator will automatically reverse the document out.

Fusion Plus™ 6000L



Fusion Plus™ 7000L



If you wish to recover a partially fed pouch press and hold the “Reverse” button and the pouch will be quickly reversed out of the laminator. You will hear a series of single beeps until Reverse button is released.

If you try to feed your pouch into the laminator before it is ready  the laminator will detect this and run the rollers in reverse. Please wait until ready light is lit.

If the laminator emits a continuous audible beep and the jam icons flashes but there is no obvious jam please check there are no documents in either the front or rear of the laminator.

Fusion Plus™ 6000L



Fusion Plus™ 7000L



NOTE: Never reuse a misfed or jammed pouch

NOTE: Do not put partially laminated items back into the laminator.



Intelligent Power Off

For added safety and environmental reasons the laminator will automatically go into sleep mode after 30 minutes of inactivity. You will hear a single beep before this occurs.

cleaning



WARNING: UNPLUG THIS PRODUCT BEFORE CLEANING THE EXTERIOR. WIPE EXTERIOR ONLY WITH A DAMP CLOTH AND DO NOT USE DETERGENTS OR SOLVENTS.

Regularly feed a cleaning card or sheet of paper through the laminator to clean the rollers. Cleaning sheet order code: EK50000.

guarantee

Operation of this machine is guaranteed for two years from date of purchase, subject to normal use. Within the guarantee period, ACCO Brands Europe will at its own discretion either repair or replace the defective machine free of charge. Defects due to misuse or use for inappropriate purposes are not covered under the guarantee. Proof of date of purchase will be required. Repairs or alterations made by persons not authorised by ACCO Brands Europe will invalidate the guarantee. It is our aim to ensure that our products perform to the specifications stated. This guarantee does not affect the legal rights which consumers have under applicable national legislation governing the sale of goods.